



PANNEAUX AFFICHAGE À RESSORTS BASE MÉTALLIQUE

NOTICE DE MONTAGE



Descriptif produit

- Utilisation idéale à l'extérieur, étanches, résistants aux coups de vents.
- 2 faces d'affichage Cadre-Clic en alu anodisé naturel, ep. 4 cm.
- Protecteurs plexi polycarbonate incassable anti-reflets (PET).
- Bases en tube 4 cm, acier laqué époxy gris alu.
- Piètements à 4 ressorts flexibles, traités anti-corrosion.
- 3 formats : A1, A0, 100 x 70 cm.

ÉTAPES DE MONTAGE



1 Assemblez la partie supérieure avec les vis.

Connect the top part on to the screws.




2 Fixez le tube du milieu sur les vis.

Connect the middle connector tube on to the screws.




3 Fixez les tubes (pieds) droite et gauche sur les vis.

Fix the right and left leg tubes on to the nuts.




4 Fixez les pièces plastiques sur les tubes puis placez les écrous.

Attach the connecting bottoms part on to the tubes so that it will grab on it tightly then place the nuts.



5 Placez la rondelle et serrez les écrous.

Adjust the washer and the nut then tighten them.



6 Ouvrez tous les profilés.

Open all profiles.



7 Retirez la protection anti-reflets.

Take-off the anti-reflex cover.



8 Placez l'affiche, remplacez la protection et refermez les profilés.

Place in the poster. After placing the cover back on the poster, close all profiles.